

# LUBIX



**Hoco EW17 Wireless Earbuds -  
Bluetooth 5.3 - White and black -  
Suitable for Apple & Android**

01-008A  
lubiX

**lubiX** would like to thank you very much for your purchase.

**lubiX** recommends that you always read the manual carefully before use and that you also perform the actions according to the manual.

**lubiX** is available for questions, complaints or other comments. Reach our customer service:

- *Mail: [contact@lubix.nl](mailto:contact@lubix.nl)*

## ENGLISH USER MANUAL

### - The earpods explained Components

1. Charging case
2. Wireless earphones
3. Eartips
4. Charging cable

The charging case (1) is 'the house' for the earphones, you can store the earphones in it when you're not using them, so you won't lose them, and that's how they charge!


The wireless earphones (2) are the earphones from which the sound comes out, which you place in your ears, one on the left and one on the right.

The earphones come with 2 x 3 sizes of ear tips (3), which you can place on the earphones to adjust the fit; to your own size! If they fit well, the earphones also sound better!

You can charge the charging case with the charging cable (4), and that charging case can charge the earbuds again!



## To use



## To connect

1. After opening the charging case, the earphones will make a sound and they are ready to connect.  
Do they give no sound, or can't you find them in your bluetooth settings? Then make sure the earbuds are charged.
2. The earphones can then be found between Bluetooth devices, as device "HOCO EW22".

## Bedieningsknopjes

- Pause / continue playing: gently click once on the touch area, from one of the ears.
- Next song: gently click twice on the touch area, from one of the ears.
- Previous song: gently click the touch area three times, from one of the ears.
- Call up "Siri": gently press and hold the touch area, for about 2 seconds, from one of the earpieces.
- Answer call, or hang up: Click, or double-click on the touch area of one of the earpieces. This only works when you receive a call or are on a call.
- Reject call: gently press and hold the touch area, for about 2 seconds, from one of the earpieces. This only works when you receive a call.

The earphones will turn off automatically after they are in the closed charging case for a maximum of 3 minutes.

### **Charge**

The earphones are charged in the charging case, place them in the charging case for this, and then close the charging case.

The charging case is charged by the supplied USB-C cable.

## ENGLISH MANUAL

# IMPORTANT PRECAUTIONS

Basic safety precautions should be followed when using this product, including:

### > READ ALL INSTRUCTIONS BEFORE USE

- Before use, inspect all parts for scratches, holes, tears, worn areas, discoloration or loose stitching, and other unusual issues. If something is wrong with a part, do not use the product and contact our customer service as soon as possible.
- This product is not a toy, so it is not intended to be played with. So also keep the elements away from children, pets or any other individuals who need supervision.
- Close supervision is necessary when used by or near children.
- Before use, check that all parts are correctly positioned and attached.
- Use all parts only and always responsibly.  
lubiX cannot be held accountable and/or responsible for the possible consequences of using this product.
- Keeps the parts from being too hot (> 35 degrees Celsius) or too cold (< -15 degrees Celsius) for a long time.
- Only use the elements if they are correctly adjusted, so the product should not be too big or too small for you.
- Use the parts only in the way for which they are intended.
- Only use this product in responsible and thoughtful ways. Misuse of can lead to injuries and accidents.
- Clean all elements regularly.
- Do not disassemble and/or attempt to modify this product.
- This product is not intended for use in the freezer or microwave.
- Avoid cleaning with chemical tools. Regular cleaning with just a damp cloth is sufficient.
- Keeps non-watertight elements out of damp areas.
- Avoid strong shocks or impacts.
- Never leave the device unattended when it is in use.
- Remove the charging case from the charger when it is completely full.
- Keep this product away from water while charging.
- Only charge this product in the manner specified in the user manual.
- If the earphones, charging case or charger smokes, emits a foul odor, heats up or shows abnormal symptoms, there may be a risk of fire or electric shock, take the following measures as soon as possible:

1. Disconnect the charger / charging cable from the wall socket when charging is in progress.
  2. Turn off the device.
- Do not use the charger for objects other than this device.
  - If you ever notice any abnormalities (including skin rash or irritation), stop using this device immediately and consult a physician.

**THIS PRODUCT IS FOR HOUSEHOLD USE ONLY**

**> PACKAGE CONTENTS**

**1x Charging case**

> Supplied in the color ordered



**2x Wireless earphones**

> Supplied in the color ordered



**6x Eartips (2 x 3 sizes)**

> Supplied in the color ordered



**1x USB-C charging cable**

> Supplied in white





## **> CLEAN AND STORE YOUR ELEMENTS**

To clean the elements, we recommend wiping with a damp cloth. Do not use soap or other cleaning agents on the elements as they may damage and/or weaken the materials.

We recommend storing this product and associated elements in a cool, dry place away from moisture, heat and direct sunlight.

SAVE THESE INSTRUCTIONS

[WWW.LUBIX.NL](http://WWW.LUBIX.NL)

[CONTACT@LUBIX.NL](mailto:CONTACT@LUBIX.NL)